

### Installation of Accordion Skirting

1. Remove skirting carefully from packaging.
2. Determine the top of the skirt by looking for the ventilating panel. The ventilating panel (if requested) is located at the top of the skirt.
3. Use care in slipping the skirt over the deck of the lift. The skirt should drop over the top of the deck as the table is slightly elevated. The skirt may have to be rotated to facilitate this step.
4. If ordered with hook and loop closures, peel off the adhesive backing of the hook and affix it to the lift. Match the pre-sewn loop on the skirt to the hook on the lift.
5. If ordered with upper hardware, lower the deck after the skirt has been slipped over it and sandwich the upper attaching fold (the one with the ventilating panel close to it) between a 1" and .125" flat bar of aluminum and the outside flange of the deck. Using 3/16" stainless steel pop rivets or tex screws (self-tapping screws) attach the flat bar to the deck. Tex screws or pop rivets should be no farther than 12" apart (the closer the better).
6. If ordered with a weight rod, raise the deck to allow for installation of the .375" steel rod to be slipped into the lower pocket of the skirt. If necessary, attach rod to the floor or use the same hardware as top attachment to attach to the bottom of the lift. Most applications require no attachment of lower rod to floor or bottom of lift.
7. Slowly raise and lower the lift and observe the skirting's performance. **Stop motion of lift before damage occurs to skirting.**
8. If questions arise, please contact Foremost toll free at 800.638.1942.